





FRONT OF PANEL SHOULD BE FACING OUT WHEN INSTALLED

BACK OF PANEL SHOULD NOT BE FACING OUT

SCREW SHOULD NOT GO IN ACCESSORY GROOVE